



Technical data sheet

CLEAMEN 300/400

Volume: 1 L
5 L

Product code: VC300010098
VC300050097



Product description:

A concentrated product designed for dilution for both daily and periodic cleaning, the removal of stains and films from all surfaces in sanitary and bathroom areas. It removes stains and sediments from toilets, urinals and other utility devices, tiling, shower corners, taps and acid resistant flooring. It is pleasantly perfumed and is also suitable for washing internal parts of refrigerators, freezers, prior to initial use. Afterwards, CLEAMEN 100/200 can then be used.

Instruction of use:

It can be also applied as a WC cleaner using a spray from CLEAMEN mobile-set or else by use of a 360° pressurized diffuser.

Note: It is unsuitable for surfaces which are non resistant to acids.

Application:

Use a machine, bucket & mop, diffuser, on a sponge with white or red padding.

DILUTING:

Using 1Ltr bottle:

Always use specified personal hand protection equipment for work.

1. Prepare the bottle designed for dilution or bucket for preparing the solution.
2. Pour the specified amount of water in the bottle or bucket designed for diluting depending on the required volume of diluted solution.
3. Take the bottle with the concentrate and select the required amount of the concentrate (use water gauge and volume scale on the bottle).
4. Pour the measured amount directly or funnel it into the diluting vessel.
5. Apply the prepared diluted solution as per your selected technological procedure.

dosing according to the level of pollution			
Sprey cleaning	●	●●	●●●
ml/1 liter	4	6	10
pH of agent	3,6	3	2,6
wet cleaning	●	●●	●●●
ml/10 litres	6	10	20
pH of agent	6,7	6,3	5,3

Physical and Chemical properties:

Form: Solid
pH: 1,00-2,00
Colour: Pink
Odour: Characteristic



Instruction about storage:

> 5 °C < 25 °C. Protect against freeze.

CORMEN s.r.o.
Průmyslová 1420
Bystřice nad Pernštejnem
593 01



DANGER.

May be corrosive to metals. Causes severe skin burns and eye damage.

Precautionary statements: Keep out of reach of children. Keep only in original packaging. Wear protective gloves/protective clothing/eye protection/face protection. IF SWALLOWED: Rinse mouth. Do NOT induce vomiting. IF ON SKIN (or hair): Take off immediately all contaminated clothing. Rinse skin with water or shower. IF IN EYES: Rinse cautiously with water for several minutes. Remove contact lenses, if present and easy to do. Continue rinsing. Immediately call a POISON CENTER/doctor. Dispose of contents/container to hazardous or special waste collection point, in accordance with local, regional, national and/or international regulation.

Manufacturer:

CORMEN, s.r.o., 593 01, Věchnov 73

Tel: +420 565 400 300, Fax: +420 566 551 822

E-mail: cormen@cormen.cz, www.cormen.cz

Issued: 28.7.2022