



Technical data sheet

CLEAMEN 240

Volume: 1,1 kg Product code: VC240010099



Product description:

A concentrated product for direct use of the removal of burns from ovens, grills and hoods. It is to be used undiluted. Gloves are required. It is important to leave the product to react with the dirt (grease, burns) for 5 to 20 minutes depending on the intensity.

Note: Not to be used on aluminium and materials non-resistant to alkaline. It is unsuitable for fan forced ovens.

Instruction of use:

Apply the product onto the dirtied part of grills, hobs, hoods, using a diffuser. Leave to react. If it is possible, pre-heat the surface to be cleaned so that the reaction will be faster. However, the temperature must not exceed 500 C.

After the reaction time, clean with water using a sponge and wipe dry. Always use gloves! We recommend using special CLEAMEN mobile-set with mobile diffuser and a bottle on a belt. It is also suitable to use CLEAMEN pressurized diffuser for feasier application of the product.

Physical and Chemical properties:

Form:	Liquia		
pH:	14		
Colour:	Colourless		
Odour:	Characteristic		

dose	level of pollution		
	•	••	•••
time (min.)	5	10	15

Instruction about storage:

> 5 °C < 25 °C. Protect against freeze.

DANGER.

May be corrosive to metals. Harmful if swallowed. Causes severe skin burns and eye damage.

Precautionary statements: Keep only in original packaging. Wear protective gloves/protective clothing/eye protection/face protection. IF SWALLOWED: Rinse mouth. Do NOT induce vomiting. IF IN EYES: Rinse cautiously with water for several minutes. Remove contact lenses, if present and easy to do. Continue rinsing. IF ON SKIN (or hair): Take off immediately all contaminated clothing. Rinse skin with water or shower. Immediately call a POISON CENTER/doctor. Dispose of contents/container to hazardous or special waste collection point, in accordance with local, regional, national and/or international regulation.

Manufacturer:

CORMEN, s.r.o., 593 01, Věchnov 73

Tel: +420 565 400 300, Fax: +420 566 551 822 E-mail: cormen@cormen.cz, www.cormen.cz

12.10.2022