



Disinfectant based on hydrogen peroxyde

Product Description

Cid Clean can be used for the disinfection of surfaces, materials, floors, walls and CIP systems in the food industry.

Properties

Cid Clean has a bactericidal action.

Composition: according to regulation (EU) 528/2012: 49,5% hydrogen peroxyde (CAS no.: 7722-84-1).

Use in PT3 (Biocide for veterinary purposes), PT4 (Biocide for the food industry) and PT5 (treatment for drinking water).

Only for professional use. Concentrated hydrosoluble solution.

Instructions

- For rooms, surfaces and materials:

Rinse surfaces thoroughly before application. Use a 4% solution of Cid Clean and apply the product by spraying (low pressure, large drops), scrubbing or soaking. Rinse after a contact time of 60 minutes.

- For CIP installations:

Rinse the CIP system thoroughly. Let circulate a 4% solution of Cid Clean (cold or warm) during a contact time of 60 minutes. Rinse after application.

- For disinfection of drinking water:

Clean heavily soiled surfaces before application.

Continuous dosage with a 0,025% solution with an automatic dosage system.

Check the Marketing Authorization of your country for more information. Not all uses can be allowed in all countries.

Specifications

Physical state	Liquid
Colour	Colourless
pH	ca 1.5
Freezing point	-20 °C
Relative density	ca 1.2
Solubility in water	100 %

Storage and Disposal

Store and handle as though always a serious potential fire/explosion and health hazard exists. Keep container closed when not in use. Store away from direct sunlight or other heat sources. Hazardous waste. Keep away from heat. Dispose in a safe manner in accordance with local/national regulations.

Safety instructions for the user

Avoid contact between alkaline and acid products. Always test the product first on a small surface.

Consult your Cid Lines sales' person for a suitable cleaning- and disinfecting program that is adjusted according to the contamination and the specific conditions of the company.

Before use, please check the MSDS.

Use biocides safely. Before use, read the label and the information concerning the product.

Not all CID LINES products are available in all countries. For information about availability of a specific product, please contact your CID LINES dealer.

CID LINES

Waterpoortstraat 2, 8900 Ieper (Belgium)
T +32 (0)57 21 78 77 • F +32 (0)57 21 78 79
info@cidlines.com • www.cidlines.com

